# Parts list

1. Base Plate

2. Mounting Bracket

3. Entrapment Brackets (2 required)

4. Adhesive Mat Assembly

5. Screws (4 required)

6. Lock

7. Laptop Computer

8. Mounting Surface

9. Mounting Bolts or Screws

FIG 1

LAPTOP STAND
HEINTZ TECHNOLOGIES, L.L.C.
603 N MAIN, MARINE CITY, MI 48039
KEVIN HEINTZ (810) 765-5578

2. Mounting bracket

1. Base plate

4. Adhesive Mat

6. Lock

5. Screws

3. Entrapment brackets
(2 required per unit)

9. Mounting screws or bolts

7. Laptop computer

8. Mounting / Work Surface

FIG 2

LAPTOP STAND
HEINTZ TECHNOLOGIES, L.L.C.
603 N MAIN, MARINE CITY, MI 48039
KEVIN HEINTZ (810) 765-5578

5. Screws

3. Entrapment brackets

7. Laptop computer

1. Base plate

2. Mounting bracket

7. Laptop computer

FIG 3

LAPTOP STAND
HEINTZ TECHNOLOGIES, L.L.C.
603 N MAIN, MARINE CITY, MI 48039
KEVIN HEINTZ (810) 765-5578

1. Base Plate

FIG 4

LAPTOP STAND
HEINTZ TECHNOLOGIES, L.L.C.
603 N MAIN, MARINE CITY, MI 48039
KEVIN HEINTZ (810) 765-5578

2. Mounting bracket

FIG 5

LAPTOP STAND
HEINTZ TECHNOLOGIES, L.L.C.
603 N MAIN, MARINE CITY, MI 48039
KEVIN HEINTZ (810) 765-5578

3. Entrapment Bracket

FIG 6

LAPTOP STAND
HEINTZ TECHNOLOGIES, L.L.C.
603 N MAIN, MARINE CITY, MI 48039
KEVIN HEINTZ (810) 765-5578

Adhesive Mat Plate

Pressure Sensitive Adhesive

FIG 7

LAPTOP STAND
HEINTZ TECHNOLOGIES, L.L.C.
603 N MAIN, MARINE CITY, MI 48039
KEVIN HEINTZ (810) 765-5578

2. Mounting bracket

1. Base plate

6. Lock

4. Adhesive Mat

3. Entrapment brackets

7. Laptop computer